
## **ASSEMBLY INSTRUCTIONS**



## CART ASSEMBLY INSTRUCTIONS MODEL 97105 & 97106



## CAUTION: DO NOT OVERTIGHTEN SCREWS

## Assembly Instructions

- 1. Using six Washers (Ref. 5) and six Screws (Ref. 6) assemble six Connecting Rods (Ref. 4) to one Frame (Ref. 1)
- 2. Set above Assembly so that the Frame is resting on the floor and the Connecting Rods are pointing upwards. Then slide three Shelves (Ref. 3) over Connecting Rods.
- 3. Position second Frame over Connecting Rods and using the remaining six Washers and six Screws, tighten Assembly.
- 4. Set Assembly upside down on the floor. Assemble four Caster Adaptors (Ref. 2) to Frame by tapping them lightly with a hammer until Adapters are seated all the way into the Frame.
- 5. Set Assembly upside down on the floor. Assemble four casters (Ref. 9) by tapping them lightly with a hammer until stems are seated all the way into the Caster Adapter.

The Vollrath Company, L.L.C. P.O. Box 611 Sheboygan, WI 53082-0611 Telephone (920) 457-4851