



E

E. VINTAGE SQUARE BAKERY CASE

ITEM 3610 | 21Wx17Dx23¼H



F

F. MONTEREY BAKERY CASE NEW

ITEM 4312-15 | 21Wx17Dx23¼H

G. GRANADA CASE DISPLAY

Includes 3 – 13" x 18" Clear Acrylic Trays.
Self and Attendant Serve with 3 Tray Positions.

ITEM 4034-85 | 19¼Wx13½Dx20¼H

ITEM 325-13-12 | Replacement Tray



G

Now a reversible design for self or attendant serve!
Featuring 3 different tray positions: tilted front, tilted back, and level.

H. MIDNIGHT BAMBOO BAKERY DISPLAY CASE

Includes 3 – 13" x 18" Black Acrylic Trays.
Self and Attendant Serve with 3 Tray Positions.

ITEM 284-96 | 21¾Wx16¼Dx21½H

ITEM 325-13-13 | Replacement Tray

H



284-96

Now a reversible design for self or attendant serve!
Featuring 3 different tray positions: tilted front, tilted back, and level.

I. GLACIER DISPLAY CASE

Includes 3 – 10" x 14" Clear Trays.

ITEM 1501-13 | 16Wx12Dx19H

ITEM 335-10-12 | Replacement 10x14 Tray



1501-13