

Info & Policy

>> Care & Use Instructions

- Handle Melamine dinnerware like any quality dinnerware.
- Use only plastic pads or plastic type bristle to remove dried food.
- Pre-soak Melamine products, if necessary, in a high quality pre-soak dishwashing detergent. Consult with your chemical supplier for the best solution to use.
- **DO NOT** use Melamine products in an oven.
- **DO NOT** use Melamine products in a microwave.
- **DO NOT** use harsh or abrasive cleaners, steel wool, or metal scouring pads.
- **DO NOT** use chlorine bleach!
- Heat Rating up to 200°F.