

Display Covers (Cover Only)

- Covers enhance and protect the look of your food items; helps keep food fresh
- Use for merchandising fresh fruits, desserts, salads, sandwiches or bakery items
- Polycarbonate dome covers add increased durability and can be used in more extreme foodservice applications



PSD21EH

Use Display Covers with our full- and half-size food pans shown on pages 224-225

Cake Covers & Tray

- Clear covers display desserts and pastries
- Sanitary covers help keep foods fresher longer
- Dishwasher safe



2512

3004

SC32

Step Risers

- Step Risers create height in your food presentation
- Offers better visibility and helps merchandise foods

Polycarbonate Step Risers

- 6843 polycarbonate riser is virtually unbreakable; won't dent or chip

ABS Step Risers

- Edges have air slots for increased air circulation
- ABS plastic is very durable and easy to clean; will not warp or chip
- Textured satin finish decreases glare, hides scratches



6863

6843



Prod No	Description	Pack
Display Covers (Trays Not Included)		
PSD13EH ♦	12" x 10" End Cut Display Cover	1 ea
PSD13CH ♦	12" x 10" Center Cut Display Cover	1 ea
PSD21EH ♦	12" x 20" End Cut Display Cover	1 ea
PSD21CH ♦	12" x 20" Center Cut Display Cover (7.88" x 6.75" opening)	1 ea
PSD21DEH ♦	12" x 20" Double End Cut Display Cover	1 ea
Cake Covers & Tray		
SC32	12" x 6" Cake Cover, Acrylic	6 ea
2512	12" x 6.5" Cake Cover, SAN	6 ea
3004	14" Display Tray, SAN	12 ea
Step Risers		
6843 ▲ ♦	11.75" 3-Step Polycarbonate Riser**	1 ea
6863	23.5" 3-Step Riser ABS Riser	1 ea

NSF Listed products are designated with a ▲ and may be prefixed with an N

**Item available by special order only

♦ California Residents: Bisphenol A **WARNING:** See appendix A on page 1