

## **Cleaning and Preventative Maintenance**

- **DAILY** Complete a wipe down of the interior of the oven. After the glass has cooled, wipe the interior glass and in-between the door and interior glass, and gasket.
  - Use hot soapy water (dish soap degreaser, Dawn, Etc.) with a towel or soft scrub pad
  - Do not use abrasive or metal scouring pads, as they could damage the oven surfaces
- DAILY Check the oven gasket for damage and replace as required or once a year
- **DAILY** Verify nothing is placed on top of the machine blocking the vent
- WEEKLY Remove racks and clean with a mild detergent and hot water, using a soft-bristled brush. Wipe down the outside of the oven and the baffles on the grill that covers the fans and electronics.
- **MONTHLY -** Pull all racks and baffle. Do not spray cleaner directly on to the elements or the door glass if it is above room temperature. If needed, deep clean with spray oven cleaner.
- EVERY 6 -12 MONTHS Oven controls and mechanical parts should be checked, adjusted and cleaned by a qualified authorized service technician.