


# Convotherm mini easyTouch – Quick Reference Guide for Cooking



## Hot surfaces

Risk of burns when there are high temperatures on the inside

Turn on the combi oven



Press the 'Cook' icon




## Hot steam

Risk of scalding when hot steam comes out when the unit door is opened

Select an operating mode




Set the cooking temperature




## Hot food

Risk of scalding posed by hot liquids when food is taken out


Delete the old value



Enter a new value



Confirm the value



Set your time OR probe cook



Delete the old value




Enter a new value




Confirm the value




Start



Pre-heat / Cool down




Ready for food




Open the unit door



Put the food inside



Close the unit door




Cooking will start – please wait



Cooking done



Open the unit door



Take food out



### Legend:

- |  |                 |  |               |  |       |
|--|-----------------|--|---------------|--|-------|
|  | Cook            |  | Steam         |  | Start |
|  | easyStart       |  | Combi-steam   |  | Stop  |
|  | Quick selection |  | Hot air       |  |       |
|  | Rethermalize    |  | Cooking temp. |  |       |
|  | Cookbook        |  | Cooking time  |  |       |
|  | Clean           |  | Core temp.    |  |       |
|  | Settings        |  | Help          |  |       |