

Convotherm mini easyTouch – Quick Reference Guide for Fully Automatic Cleaning

⚠️ WARNING

Contact with cleaning agents
Risk of chemical burns and skin, eye, and respiratory tract irritation


⚠️ WARNING

Hot surfaces
Risk of burns when there are high temperatures on the inside and at the combi oven vents


⚠️ WARNING

Spraying water inside while the oven is hot
Risk of scalding posed by hot steam


Open/empty the oven




Turn the rotor



Check cleaning agents




Check connections




Press the 'Clean' icon




Select a cleaning profile




Check the inside




Close the unit door



Cleaning will start – please wait




Cool down, please wait




Cleaning will start automatically




Cleaning in progress – please wait




Cleaning done – please confirm




Open the unit door / check results



Clean oven drain



Turn off the combi oven




Leave unit door ajar



Legend:

	Clean		Semi-automatic
	Fully automatic: Level 1 - light		CareStep
	Level 2 - medium		Express
	Level 3 - heavy		
	Level 4 - very heavy		Stop

Weekly manual cleaning:



- 1) Fan screen
 - Clean by hand with a slightly damp cloth and common household dishwashing liquid
- 2) Hygienic gasket
 - Wipe clean by hand using a soft cloth and common household dishwashing liquid
 - Wipe clean with a soft cloth and water
- 3) Door drip tray
 - Clean by hand using a soft cloth and common household dishwashing liquid
 - Wipe clean with a soft cloth and water

These instructions are meant to supplement the operating manual for your unit and should only be used together with it while observing all safety information and instructions.