


**Hot/Cold Well and Heated Well Accessories** *(available for purchase at any time)*


**HWB-2-7Q**  
(shown with  
two 7QT-PAN  
and 7QT-LID-1)



**HWB-2-7Q**



**HWB-2-11Q**



**HWB-3-4Q**

**ADAPTERS – SUPPORT BARS**

|                   |  |
|-------------------|--|
| <b>HWB-2-7Q</b>   | Adapter to convert warmer to hold two (2) 7-Quart Inserts (HWB-FUL & HWBI-FUL models only)   |
| <b>HWB-3-4Q</b>   | Adapter to convert warmer to hold three (3) 4-Quart Inserts (HWB-FUL & HWBI-FUL models only) |
| <b>HWB-2-11Q</b>  | Adapter to convert warmer to hold two (2) 11-Quart Inserts (HWB-43 model only)               |
| <b>HWB12BAR</b>   | 12" Pan Support Bar for Built-In and Drop-In Heated Wells                                    |
| <b>HWB20BAR</b>   | 20" Pan Support Bar for Built-In and Drop-In Heated Wells                                    |
| <b>HWBGM12BAR</b> | 12" Pan Support Bar for Drop-In Modular/Ganged Models  |
| <b>HWBGM20BAR</b> | 20" Pan Support Bar for Drop-In Modular/Ganged Models  |

**Support Bars**  
Choose the appropriate kit for  
HWBI or HWB series



**MOUNTING KITS – VALVES**

**Necessary at your Well installation –**

|                    |  |
|--------------------|--|
| <b>HWB-FUL-MNT</b> | Mounting Kit for combustible countertops (HWB-FUL series only)                                   |
| <b>HWB-43-MNT</b>  | Mounting Kit for combustible countertops (HWB-43 series only)                                    |
| <b>HWB-4Q-MNT</b>  | Mounting Kit for combustible countertops (HWB-4Q series only)                                    |
| <b>HWB-7Q-MNT</b>  | Mounting Kit for combustible countertops (HWB-7Q series only)                                    |
| <b>HWB-11Q-MNT</b> | Mounting Kit for combustible countertops (HWB-11Q series only)                                   |
| <b>HWB-MNT-REC</b> | Kit allows mounting to thick countertops – 8 Brackets (HWBI & HWB Rectangular Heated Wells only) |
| <b>HWB-MNT-RND</b> | Kit allows mounting to thick countertops – 4 Brackets (Round Heated Wells only)                  |



**External Manifold includes individual Ball Valve for each well (HWBI only – not available on the Slim models) –**

|                   |                 |
|-------------------|-----------------|
| <b>HWBI2MANIF</b> | 2-Pan Accessory |
| <b>HWBI3MANIF</b> | 3-Pan Accessory |
| <b>HWBI4MANIF</b> | 4-Pan Accessory |
| <b>HWBI5MANIF</b> | 5-Pan Accessory |
| <b>HWBI6MANIF</b> | 6-Pan Accessory |

**Necessary at your Well installation –**

|                       |   |
|-----------------------|---|
| <b>BALLVALVE3/4</b>   | High Temperature 3/4" NPT Ball Valve for units with individual Drain(s) and no Manifold             |
| <b>BALLVALVE1INCH</b> | High Temperature 1" NPT Ball Valve for units with Manifold Drain (Modular/Ganged Heated Wells only) |
| <b>GATEVALVE3/4IN</b> | High Temperature 3/4" NPT Gate Valve for units with individual Drain(s) and no Manifold             |
| <b>GATEVALVE1IN</b>   | High Temperature 1" NPT Gate Valve for units with Manifold Drain (Modular/Ganged Heated Wells only) |
| <b>HWB-RDH</b>        | Heated Well Remote Handle for 3/4" Drains only (includes a Ball Valve)                              |


**HWB-FUL-MNT**  
Choose the appropriate kit for  
HWB-FUL, HWB-43 or HWB-  
4Q, -7Q, -11Q Series




**HWB-MNT-REC or  
HWB-MNT-RND**



**GATEVALVE1INCH**



**HWB-RDH**  
Attaches to 3/4" ball  
or gate valve



**HWBI2MANIF**