

PROPER USE AND CARE INSTRUCTIONS

- See “Bonstone Tile and Carving Board Proper Care and Use instructions” for your Bonstone carving board that shipped with your Carving Station.
- Use a water-based spray or non-abrasive stainless steel product to clean heat lamp and base.
- Do not submerge in water.
- Do not plug in with wet hands.
- Do not plug into a socket where several other appliances are plugged in.
- Do not use if the plug cord is damaged or the power plug does not fit the socket safely. Cord replacement must be done by a qualified technician.
- Do not modify the parts, or repair the unit yourself.
- Do not use the unit near flame or wet places.
- Do not use where children can easily touch the unit, or allow children to use the unit by themselves.
- Do not place on unstable surfaces.
- Do not move the unit when in use.