

**Saucer**

| | | |
|------|------------------|-------|
| DR-2 | 6½" (Fits DR-23) | 3 doz |
|------|------------------|-------|

**A.D. Saucer**

| | | |
|-------|------------------|-------|
| DR-38 | 4¾" (Fits DR-37) | 3 doz |
|-------|------------------|-------|

**Stackable Cup**

| | | |
|-------|---------------------|-------|
| DR-23 | 3⅝" D x 2½" H (8oz) | 3 doz |
|-------|---------------------|-------|

**A.D. Cup**

| | | |
|-------|-----------------------|-------|
| DR-37 | 2¾" D x 1⅞" H (3.5oz) | 3 doz |
|-------|-----------------------|-------|

**Mug** NEW

| | | |
|-------|----------------------|-------|
| DR-68 | 3¼" D x 3⅝" H (11oz) | 2 doz |
|-------|----------------------|-------|

**Creamer**

| | | |
|--------|---------------------|-------|
| DR-100 | 4⅝" D x 3" H (10oz) | 1 doz |
|--------|---------------------|-------|

*with handle

**Salt & Pepper Shakers**

| | | |
|--------|--------------|------------|
| DR-101 | 2" D x 2⅝" H | 1 doz sets |
|--------|--------------|------------|

**Sugar Packet Holder**

| | | |
|--------|-------------------|-------|
| DR-225 | 3¼" x 2⅞" x 2¼" H | 3 doz |
|--------|-------------------|-------|



Matching
flatware
available
on pages
199 & 210.