



CS-70-MA  
Round Bread Plate  
7"  
1 dz.



CS-90-MA  
Round Dinner Plate  
9"  
1 dz.



CS-100-MA  
Round Dinner Plate  
10.5"  
1 dz.



B-80-MA  
Round Side Dish Bowl  
8 oz. 5" dia.  
2" H  
2 dz.



B-180-MA  
Round Salad Bowl  
16 oz. 7" dia.  
1.75" H  
1 dz.



B-420-MA  
Round Pasta Bowl  
1.3 qt. 10" dia.  
1.75" H  
1 dz.



CS-1170-MA  
Rectangular Platter  
12" L x 7.5" W  
1 dz.



CS-70-TP  
Round Bread Plate  
7"  
1 dz.



CS-90-TP  
Round Dinner Plate  
9"  
1 dz.



CS-100-TP  
Round Dinner Plate  
10.5"  
1 dz.



B-80-TP  
Round Side Dish Bowl  
8 oz. 5" dia.  
2" H  
2 dz.



B-180-TP  
Round Salad Bowl  
16 oz. 7" dia.  
1.75" H  
1 dz.



B-420-TP  
Round Pasta Bowl  
1.3 qt. 10" dia.  
1.75" H  
1 dz.



CS-1170-TP  
Rectangular Platter  
12" L x 7.5" W  
1 dz.



CS-70-GR  
Round Bread Plate  
7"  
1 dz.



CS-90-GR  
Round Dinner Plate  
9"  
1 dz.



CS-100-GR  
Round Dinner Plate  
10.5"  
1 dz.



B-80-GR  
Round Side Dish Bowl  
8 oz. 5" dia.  
2" H  
2 dz.



B-180-GR  
Round Salad Bowl  
16 oz. 7" dia.  
1.75" H  
1 dz.



B-420-GR  
Round Pasta Bowl  
1.3 qt. 10" dia.  
1.75" H  
1 dz.



CS-1170-GR  
Rectangular Platter  
12" L x 7.5" W  
1 dz.



CS-70-GBL  
Round Bread Plate  
7"  
1 dz.



CS-90-GBL  
Round Dinner Plate  
9"  
1 dz.



CS-100-GBL  
Round Dinner Plate  
10.5"  
1 dz.



B-80-GBL  
Round Side Dish Bowl  
8 oz. 5" dia.  
2" H  
2 dz.



B-180-GBL  
Round Salad Bowl  
16 oz. 7" dia.  
1.75" H  
1 dz.



B-420-GBL  
Round Pasta Bowl  
1.3 qt. 10" dia.  
1.75" H  
1 dz.



CS-1170-GBL  
Rectangular Platter  
12" L x 7.5" W  
1 dz.