



CS-70-MA
Round Bread Plate
7"
1 dz.



CS-90-MA
Round Dinner Plate
9"
1 dz.



CS-100-MA
Round Dinner Plate
10.5"
1 dz.



B-80-MA
Round Side Dish Bowl
8 oz. 5" dia.
2" H
2 dz.



B-180-MA
Round Salad Bowl
16 oz. 7" dia.
1.75" H
1 dz.



B-420-MA
Round Pasta Bowl
1.3 qt. 10" dia.
1.75" H
1 dz.



CS-1170-MA
Rectangular Platter
12" L x 7.5" W
1 dz.



CS-70-TP
Round Bread Plate
7"
1 dz.



CS-90-TP
Round Dinner Plate
9"
1 dz.



CS-100-TP
Round Dinner Plate
10.5"
1 dz.



B-80-TP
Round Side Dish Bowl
8 oz. 5" dia.
2" H
2 dz.



B-180-TP
Round Salad Bowl
16 oz. 7" dia.
1.75" H
1 dz.



B-420-TP
Round Pasta Bowl
1.3 qt. 10" dia.
1.75" H
1 dz.



CS-1170-TP
Rectangular Platter
12" L x 7.5" W
1 dz.



CS-70-GR
Round Bread Plate
7"
1 dz.



CS-90-GR
Round Dinner Plate
9"
1 dz.



CS-100-GR
Round Dinner Plate
10.5"
1 dz.



B-80-GR
Round Side Dish Bowl
8 oz. 5" dia.
2" H
2 dz.



B-180-GR
Round Salad Bowl
16 oz. 7" dia.
1.75" H
1 dz.



B-420-GR
Round Pasta Bowl
1.3 qt. 10" dia.
1.75" H
1 dz.



CS-1170-GR
Rectangular Platter
12" L x 7.5" W
1 dz.



CS-70-GBL
Round Bread Plate
7"
1 dz.



CS-90-GBL
Round Dinner Plate
9"
1 dz.



CS-100-GBL
Round Dinner Plate
10.5"
1 dz.



B-80-GBL
Round Side Dish Bowl
8 oz. 5" dia.
2" H
2 dz.



B-180-GBL
Round Salad Bowl
16 oz. 7" dia.
1.75" H
1 dz.



B-420-GBL
Round Pasta Bowl
1.3 qt. 10" dia.
1.75" H
1 dz.



CS-1170-GBL
Rectangular Platter
12" L x 7.5" W
1 dz.