

SOUND

FORTESSA® Vitraluxe®

MIDNIGHT

CEMENT



Coupe Plates

6400.SND.1341 10.5" (26.7cm)
6400.SND.1340 8.25" (21cm)
6400.SND.1660 6" (15.2cm)



Pasta Bowl

6400.SND.1339
8.5", 28oz
(21.6cm, .8L)



Coupe Plates

6500.SND.1341 10.5" (26.7cm)
6500.SND.1340 8.25" (21cm)
6500.SND.1660 6" (15.2cm)



Pasta Bowl

6500.SND.1339
8.5", 28oz
(21.6cm, .8L)



Fitted Plates

6400.SND.1109
8.5" (22cm) fits 8.5" bowl

6400.SND.1131
6.75" (17.1cm)
fits 6.75" bowl

6400.SND.1156
6" (15.2cm) fits 6" bowl



Straight Sided Bowls

6400.SND.1119
8.5" (21cm)

6400.SND.1123
6.75" (16.9cm)

6400.SND.1108
6" (15cm)



Bowls

6400.SND.1379
8.5", 51oz (21.6cm, 1.5L)

6400.SND.1378
6", 24oz (15.2cm, .7L)



Fitted Plates

6500.SND.1109
8.5" (22cm) fits 8.5" bowl

6500.SND.1156
6" (15.2cm) fits 6" bowl



Bowl

6500.SND.1378
6", 24oz
(15.2cm, .7L)



Dipping Dish

6400.SND.1155
2oz (.065L)



Sauce Dish

6400.SND.1154
2.5" (6.35cm)



Teapot with Lid

6400.SND.1153
29oz (.85L)



Dipping Dish

6500.SND.1155
2oz (.065L)



Sauce Dish

6500.SND.1154
2.5" (6.35cm)



Teapot with Lid

6500.SND.1153
29oz (.85L)



Mug

5900.BLK.5465
14oz (.4L)
CR16-S-115T*



Cups

5900.BLK.10150
7oz (.21L) coffee
CR16-T*

5900.BLK.4626
3oz (.09L) espresso
CR30-T*



Saucers

5900.BLK.4615
5.5" (14cm) coffee

5900.BLK.4627
4.5" (11.4cm) espresso



Mug

6500.SND.1197
14oz (.4L)
CR16-S-115T*



Cups

6500.SND.4613
7oz (.21L) coffee
CR16-T*

6500.SND.4626
3oz (.09L) espresso
CR30-T*



Saucers

6500.SND.4615
5.5" (14cm) coffee

6500.SND.4627
4.5" (11.4cm) espresso



Sake Bottle

6400.SND.6103
15oz (.44L)



Teacup/Sake Cup

6400.SND.9021
4oz (.12L)



Creamers

6400.SND.2026
7oz (.2L)

6400.SND.9070
3oz (.09L)



Sake Bottle

6500.SND.6103
15oz (.44L)



Teacup/Sake Cup

6500.SND.9021
4oz (.12L)



Creamers

6500.SND.2026
7oz (.2L)

6500.SND.9070
3oz (.09L)

*Corresponding cup rack

