

Care In Use



CHURCHILL

CERAMICS

RECOMMENDATIONS TO HELP YOU TO PROTECT YOUR INVESTMENT IN CHURCHILL TABLEWARE.

CLEANING

- ☑ Upon delivery, inspect all items and wash twice before putting into service.
- ☑ It is important to follow manufacturers recommendations regarding quantity and type of detergent and rinse aids.
- ☑ Remove & rinse leftover food immediately after use.
- ☑ To avoid metal marking, use a plastic spatula to remove leftovers.
- ☑ Clean the dishwasher regularly to prevent limescale build up.
- ☑ Wash within 30-40 minutes of use.
- ☑ Allow items to air dry before stacking.
- ☑ Use a non abrasive pad when cleaning to remove stains.
- ❌ Do not put items decorated with metallics into the dishwasher.
- ❌ Do not put detergent directly onto dinnerware as this may result in damage.
- ❌ Do not mix cutlery and ceramics together when cleaning.

PREVENTING SCRATCHES & METAL MARKING

- ☑ When stacking, place plates centrally and do not push plates into a centre of a stack.
- ☑ Avoid exerting excessive pressure on the surface of the product. A lower grade cutlery will be softer and be more prone to leaving marks.
- ☑ Metal marks can usually be successfully removed by using proprietary products (in-line with manufacturing guidelines).
- ❌ Do not slide, always lift products.
- ❌ Do not put hot wet dishes into contact with aluminium surfaces.

STORAGE

- ☑ Ensure adequate storage space is provided.
- ☑ Store preferably on high-grade stainless steel shelves or shelf mats to avoid metal marking.
- ☑ Keep ceramics, metal and glassware separate.
- ❌ Do not stack hot wet ceramics.
- ❌ Do not stack items that were not designed to be stacked.
- ❌ Do not over stack, as the weight created by stacking too high will contribute to scratching and metal marking.
- ❌ Do not mix-stack e.g do not stack Churchill tableware with products from other suppliers, particularly if these items have an unglazed foot.

WARMING

CHURCHILL COOKWARE IS OVEN PROOF TO 180 DEGREES CELSIUS

- ☑ Warm gradually & evenly.
- ❌ Avoid excess temperature variations such as taking the tableware from the fridge directly to a hot oven.
- ❌ Do not place items decorated with metallics (gold, silver, bronze) in the microwave.

FEATURES & BENEFITS



*Dishwasher safe only including plastic base

Churchill China (UK) Ltd

No 1, Marlborough Way, Tunstall, Stoke-on-Trent, ST6 5NZ Tel: +44(0)1782 524358

Email: info@churchill1795.com Website: www.churchill1795.com