

# Instructions

## HID Machine Stand Assembly

1. Remove carton.
  2.
    - a. If door model open door, locate key and legs.
    - b. If basic model remove the 6 screws holding the back panel in place and then locate the legs.
  3. Remove 4 bolts holding stand to skid. **Important: Save the square nuts for the next step.**
  4. Attach legs to stand. Place stand on its side, insert legs thru clearance holes in base and inside the stand thread a square 5/8-11 nut onto each leg's threads. Tighten with wrench.
- Tip: Rotate all 4 leg feet to the minimum height before starting to level the stand.
5. Hoist HID dispenser and place on stand, do not slide. Dispenser will drop slightly when correctly located.
  6. Center dispenser left to right. Position dispenser and stand so that their backs are flush.
  7. Secure dispenser to stand with four 3/8" bolts and lock washers provided.
  8.
    - a. If door model close door.
    - b. If basic model secure back panel in place with the 6 screws removed in step 2.
  9. Place stand and dispenser in its location and rotate leg feet to level it front to back and left to right.
  10. Remove protective plastic from panels.
  11. Seal between stand and dispenser chassis (do not seal drip tray) with food grade sealant as needed for local codes.
  12. If door model check lock operation, give key to user.

Note: Door swing is reversible. Hinges have to be moved to the opposite side to change swing.