

## Hoshizaki SD-271 Cabinet Stand For Use with DCM-271BAH and DCM-271BAH-OS

Installation Instructions to attach a DCM-271 series dispenser to the cabinet stand.

- 1) Select a flat and firm installation site.
- 2) Attach the four (4) adjustable legs (included) to the stand. Adjust the legs to prevent instability.
- 3) Open the door.
- 4) Remove the two screws securing the panel and then remove the panel.
- 5) Remove the legs from the dispenser. Make sure the drain line and water supply line are disconnected from the dispenser.
- 6) Position the dispenser on top of the stand. Be sure to align the drain on the dispenser with the drain hole on the stand.
- 7) Using the four (4) bolts included with the stand, secure the dispenser to the stand.
- 8) Make the drain line and water line connections. Route the lines and the electrical cord through the grommets on the stand's rear panel.
- 9) Using the two screws, reattach the panel in its proper position.
- 10) Seal the seam all the way around between the dispenser and stand with food grade silicone.

Note: The door on the stand is reversible. To reverse the door, remove the screws securing the hinges to the stand. Rotate the door 180° and reattach on the other side.

