Instructions

Kit Numbers: KDIL-PN-200 and KDIL-PN-250

Kit Purpose: To lower the ice level in the Cornelius ice and beverage dispensers when a Scotsman Nugget ice machine is stacked on top of the dispenser. The kit also includes an ice slide to improve ice distribution on the cold plate of the dispenser, and an ice diverter kit to allow the nugget ice to dispense.

Kit Contents:

KDIL-PN-200	Ice Slide for ED/DF200	KVS	KNUGDIV	Ice Deflector
KDIL-PN-250	Ice Slide for ED/DF250	KVS	KNUGDIV	Ice Deflector

Other Requirements: Requires adapter kit KBT43. (Available from Scotsman)

Applications: N0422, N0622, N0922 or N1322 Installed on Cornelius DF200 or DF250

Installation Sequence:

- 1. ICE SLIDE Follow the separate instructions included with the Ice Slide
- 2. KNUGDIV Follow the separate instructions included with the KNUGDIV
- 3. Adapter Kit KBT43 Follow the separate instructions included with the Adapter Kit

Note: Retrofits of existing ice machine stacked on the dispenser will require a new adapter.

- 4. Ice machine Follow the separate instructions included with the Ice Machine
- 5. KVS Follow the separate instructions included with the KVS
- 6. Ice Deflector Follow the separate instructions included with the Ice Deflector

Pre-Installation check list:

- Removal of old ice machine and adapter (when used)
- Ice slide installed
- KNUGDIV installed
- Dispenser and adapter are properly installed.
- Ice machine is placed onto dispenser / adapter combo.

Installation: Dispenser



AWARNING

Electrical Shock Hazard

Disconnect electrical power before beginning

- 1. Disconnect electrical power from both the ice machine and the dispenser.
- 2. Install Ice Slide per its instructions.
- 3. Install KNUGDIV per its instructions.
- 4. Install adapter per its instructions with the exception of the baffle.
- 5. Place nugget ice machine onto adapter. Be sure to seal the ice machine to the adapter. Note: sealant is supplied with the adapter.

Ice Machine

- 6. Remove front panel.
- 7. Remove control box cover.
- 8. Install KVS ice level control per its instructions.
- 9. Set KVS adjustment knob to the recommenced position (2:00 O'CLOCK) for dispensers. See Illustration.



Recommended Position (2:00 O'CLOCK)

Note: The KVS will allow you to adjust the ice level in the dispenser. If it is adjusted to low the result will be an empty dispenser. (Don't adjusted below 3:00 O'CLOCK)

Dispenser:

Set the agitation for .5 seconds on, 3 hours off. See KNUGDIV for instructions.

Reconnect electrical power.

Return all panels and covers to their normal positions and secure with the original screws.

Scotsman 101 Corporate Woods Parkway Vernon Hills, IL 60061 1-800-533-6006

Scan or Click for Instruction

ICE SLIDE



KNUGDIV



KBT43



CVS



ICE DEFLECTOR



Manuals

