COMBITHERM

CT Express™ SIMPLE CONTROL QUICK START GUIDE

Turn on and preheat the oven

Alto-Shaam recommends preheating the Combitherm® before cooking.

- Press the **Power** key.
- Choose a Mode.





Green light will appear


while oven is booting up.

• Press **Oven Temperature** key.



Combi

- Adjust temperature with arrow keys.
- Press **Cook Time** key.



- Press the Start/Stop key.
- Preheat oven before loading food.

To cook manually by probe

• Choose a **Mode**.



Combi

Convection

 Press the Oven Temperature key; adjust temperature with arrow keys.



- Press the Probe Temperature key; adjust temperature using the arrow keys.
- Load food into oven and insert probe into food.

• Press the Start/Stop key. **Oven** Temperature area Key LED Screen 180 \bigtriangleup Cooking Arrow keys Mode Keys 10 \bigtriangledown 1 Cleaning Key Start/Stop key Cook Time Key Probe Key





Steam

• Choose a **Mode**.



 Press the Oven Temperature key; adjust temperature with arrow keys.



- Press the **Cook Time** key; adjust time using the arrow keys.
- Load food into oven.
- Press the **Start/Stop** key.



To clean the oven

• Press the **Cleaning** key.



- Insert appropriate number of CombiClean® tabs as directed by the LED Screen (CLn4 appears).
- Close the oven door and press the **Start/Stop** key.



- If oven is too hot to proceed, **dOOr** will display on the LED screen. Open the oven door to allow the oven to cool. When the oven is finished cooling, begin the cleaning procedure again.
- Oven beeps when it is done cleaning. Leave door slightly ajar when cleaning is finished.

NOTE: TO SHUT THE OVEN OFF, PRESS AND

HOLD FOR FIVE SECONDS. THE RED LIGHT WILL APPEAR INDICATING THAT THE OVEN WILL BEGIN THE SHUT DOWN PROCESS.

TO FORCE SHUT DOWN IN THE RARE EVENT THE CONTROL LOCKS UP, PRESS AND HOLD **()** FOR TEN SECONDS.



