


# **WARING** WSD1G Series – 1 Gallon Syrup Dispenser Instructions

To ensure proper operation and equipment life, please follow the instructions below for assembly, cleaning and maintenance. Be sure to clean syrup dispenser thoroughly before first use and after each use. Daily cleaning is recommended.



## **ASSEMBLY**

1. Remove the syrup dispenser from the packaging.
2. Rinse and dry syrup dispenser and lid before using. Wash using a mild soap and water solution with sponge. Take care when cleaning around the graphic overlay.
3. Place syrup dispenser on a sturdy, level surface, away from the edges of the countertop.
4. Place the syrup pump inside the syrup bottle and screw it on until tight.
5. Place the syrup bottle into the dispenser with the pump facing forward.
6. Place the lid onto the top of the dispenser housing.

## **CLEANING & MAINTENANCE**

1. Remove the lid.
2. Wash the lid and internal housing with a warm water and soap solution using a sponge or nonabrasive cloth. Take care when cleaning around the exterior graphic label.
3. Remove the syrup container from the dispenser housing.
4. Thoroughly rinse the syrup pump with a warm water and soap solution.

Washing solutions based on non-sudsing detergents and chlorine-based sanitizing solutions having a minimum chlorine concentration of 100 PPM are recommended.

The following washing, rinsing, and sanitizing solutions, or equivalents, may be used.

<b>SOLUTIONS</b>	<b>PRODUCT</b>	<b>DILUTION IN WATER</b>	<b>TEMPERATURE</b>
Washing	International Products Corporation LF2100 Liquid Low-Foam Cleaner	1%–2%: 1¼–2¾ Ounces/Gallon (lower dilution of 1% for normal cleaning and up to 2% for more stubborn soils)	Room temperature
Rinsing	Plain Water		
Sanitizing	Clorox® Regular Bleach (8.25% Hypochlorite Concentration)	2 Teaspoons/Gallon (alternately a bleach with 5.25% Hypochlorite Concentration can be used at dilution of 3 Teaspoons/Gallon)	Warm 95°F (35°C)

5. Allow all components to air-dry, or wipe dry with a nonabrasive cloth.

For additional questions, please contact Waring customer service:  
Weekdays – 8:30-4:30 EST, Call 1-800-4WARING  
Weekends – email, [service\\_waring@conair.com](mailto:service_waring@conair.com)